

VXB

Veypor External Buttons



The VXB duplicates the functions of the MENU and ENTER buttons on all Veypor and VR2 units. Please follow the installation and configuration instructions below to insure proper VXB operation.

Installation

The VXB installs inline with the existing Veypor/VR2 and wiring harness. Simply plug the VXB harness into the Veypor/VR2 and then plug the wiring harness (or other accessories such as the VIR and HUD) into the VXB.

Recommended connection order for the wiring is:

Main Harness -> VIR -> HUD -> VXB -> Veypor/VR2

Using the included aluminum clamp and screws, securely fasten the VXB to your left handlebar, within comfortable reach of your thumb.

Configuration

Make sure you are using the latest firmware for the Veypor or VR2 (at least Veypor v2.23 or VR2 v1.23).



In the Main Menu, proceed to the Configuration submenu and then choose System Configuration. Press MENU to cycle through the screens until you reach the VXB Configuration dialog. Press ENTER to toggle the option to ENABLED. Press MENU until you return to the Configuration Main Menu.